

# MAINTENANCE & CLEANING

Cleaning and disinfecting on a regular basis is very important for maintaining the performance of your humidifier. **NEVER IMMERSE HUMIDIFIER BASE IN WATER.**

**IMPORTANT:** Water left in the tank or humidifier base when not in use may result in buildup of mineral deposits and bacteria which may inhibit the output efficiency as well as void the warranty. If water remains in the Water Tank for more than a day or two, bacterial growth is possible.

## DAILY MAINTENANCE

1. Turn off, unplug from outlet and empty water from tank & humidifier base daily.
2. Allow water tank & humidifier base to air dry.
3. Leave water tank disk and mist nozzle off the water tank until ready for next use.

## WEEKLY CLEANING

1. **Turn off, unplug from outlet** and empty water from tank & humidifier base. Use a solution of 2 Tablespoons of white vinegar to 2 litres of water, to clean the humidifier
2. **Remove the Mist Channel Cover** by gently pulling from the top of the tank. Clean mist channel cover and mist channel with a white vinegar/ water solution. Wipe mist channel with white vinegar/water solution and rinse clean. **NOTE:** After cleaning, reassemble the Mist Channel Cover see page 6. **Mist Channel Cover** must be secure to operate the humidifier properly.
3. **Remove water tank disk from mist nozzle.** Wipe disk and nozzle with white vinegar/ water solution and rinse.
4. **Fill Water tank** halfway with warm water. Add 2 Tablespoons of white vinegar to water and let tank sit for 30 minutes. **Wipe down the inside of water tank** with the solution using a soft cloth. Water Tank opening allows your hand inside tank for cleaning. Empty tank and rinse with plain water.
5. **Fill humidifier base with warm water**, add 1 tablespoon of white vinegar and let sit for 30 min. Empty base & rinse with plain water. **Always** pour water away from the fan outlet when emptying.  
**TIP: Clean the nebulizer with a damp cloth or cotton swab after soaking.**
6. Allow water tank, mist channel cover & humidifier base to air dry and leave water tank disk and mist nozzle off the tank until the next use.

## Easy Cleaning:


### Step 1



### Step 2



### Step 3



## END-OF-SEASON MAINTENANCE & STORING YOUR HUMIDIFIER

1. Turn off, unplug from outlet, and empty water from tank & humidifier base.
2. Follow instructions for weekly cleaning above.
3. Let all parts dry completely.
4. Store humidifier in a cool, dry place